


8.49 EUR
incl. 19% VAT, plus [shipping](#)



PIC controller with v,1.4 firmware

For units with older firmware (or units purchased before 06/06/08). Upgrade your M2-ATX or M2-ATX-HV firmware by replacing the on-board PIC microcontroller.

06/06/2008 Firmware 1.4: Shut down while ACPI is not fully up fix via 60 second AutoLatch feature

06/06/2008 Firmware 1.4: Officially introduced 3 more timing schemes: 0001 10 minutes / 1 hour 1001 15 minutes / 2 hours 0101 1 hour / 1 hour 15 minutes

06/06/2008 Firmware 1.4: In P0 (dumb PSU mode) if ignition is used, can act as an UPS system. (consult M2-ATX product page for more information)

INSTRUCTIONS:

- 1) Remove power from M2-ATX
- 2) Remove existent chip using a flat screwdriver.
- 3) Insert new chip.